RAYNESWAY BLINDS

CARE GUIDE

Venetian and wooden blinds

Dusting and wiping slats without bending them.

Cleaning routine

Every week or two

Close the slats and dust with a soft duster or microfibre cloth, then tilt them the other way and dust the second side. Work from the top down.

Every few months

Wipe each slat with a cloth dampened in warm water and a little mild washing-up liquid, supporting it with your other hand so it does not bend. Dry afterwards.

Do

- Wipe aluminium and faux-wood slats with a damp cloth. They cope well with kitchens and bathrooms.
- Keep real wooden slats as dry as you can: dust them, and use only a barely damp cloth if they need more.
- Raise and lower the blind slowly and evenly, with the slats open.

Please avoid

- Do not soak wooden slats or use wet cloths on them.
- Do not use bleach, abrasive cleaners or solvents.
- Do not tug on the cord or force the blind if it catches.
- Do not leave the cords hanging loose. Keep them secured and out of the reach of children.

If something is not right

The blind hangs crooked

Lower it fully, then raise it again slowly. If it still hangs unevenly, the cords may need re-setting, so call us.

A slat is bent

Please do not try to bend it back. We can usually replace a single slat.

These are general guides. Always follow any care label or instructions supplied with your product, and if you are unsure about a stain, a fabric or a repair, ask us before you try anything.

Need a hand? Call 01332 280585 | sales@rayneswayblinds.com

rayneswayblinds.com/care-guides/