RAYNESWAY BLINDS

CARE GUIDE

Awnings

Keeping fabric, frame and motor in good order through the seasons.

Cleaning routine

Every few weeks in use

Brush off leaves, dust and bird droppings with a soft brush while the awning is open and dry.

Once or twice a year

With the awning open, wash the fabric with lukewarm water and a mild soap using a soft brush or sponge, rinse well with clean water and leave it open until it is completely dry. Wipe the frame and arms with a damp cloth.

Do

- Retract the awning in strong wind, heavy rain and snow.
- Make sure the fabric is fully dry before you close it for a long time.
- Book a professional check once a year, particularly for motorised awnings.

Please avoid

- Do not leave the awning open in strong wind or when you are away.
- Do not use a pressure washer, bleach or solvents on the fabric.
- Do not climb on the awning or hang anything from the arms.
- Do not force a motor or arm that is stuck. Call us.

If something is not right

Water pools on the fabric

Retract it or tilt it to drain, and tell us if the pitch needs adjusting.

It does not extend or retract smoothly

Stop using it and call us. The arms or the motor may need servicing.

These are general guides. Always follow any care label or instructions supplied with your product, and if you are unsure about a stain, a fabric or a repair, ask us before you try anything.

Need a hand? Call 01332 280585 | sales@rayneswayblinds.com

rayneswayblinds.com/care-guides/