RAYNESWAY BLINDS

CARE GUIDE

Roller blinds

Spot cleaning fabric and keeping the roll straight.

Cleaning routine

Every week or two

Pull the blind down fully and dust the fabric with a soft duster, or use a vacuum brush attachment on a low setting.

When it needs more

Dab a mark gently with a clean, damp cloth and a drop of mild washing-up liquid, then dab with clear water and let it dry fully before rolling the blind up. Test a hidden corner first.

Do

- Roll the blind up and down smoothly and let it stop at the top without snapping.
- Let the fabric dry fully before you roll it up.
- Wipe waterproof fabrics with a damp cloth. They are made for bathrooms.

Please avoid

- Do not rub hard, as it can mark or polish the fabric.
- Do not use bleach, solvents or strong stain removers.
- Do not soak the fabric or the tube.
- Do not pull the blind sideways when you lower it.

If something is not right

The blind rolls up unevenly

Lower it fully and roll it up again slowly and evenly. If the problem remains, it may need adjusting, so get in touch.

The blind will not stay down

The spring or clutch may need attention. Please call us rather than forcing it.

These are general guides. Always follow any care label or instructions supplied with your product, and if you are unsure about a stain, a fabric or a repair, ask us before you try anything.

Need a hand? Call 01332 280585 | sales@rayneswayblinds.com

rayneswayblinds.com/care-guides/