RAYNESWAY BLINDS

CARE GUIDE

Vertical blinds

Cleaning vanes, keeping them hanging straight and the track running.

Cleaning routine

Every week or two

Close the vanes and dust them with a soft duster or a vacuum brush attachment on a low setting, then turn them the other way and dust the second side.

Every few months

Wipe PVC and rigid vanes with a damp cloth and a little mild washing-up liquid, one vane at a time. For fabric vanes, dab marks gently and let them dry before closing the blind. Vacuum any dust out of the track.

Do

- Use the wand or cord to turn and draw the vanes. Do not push them by hand.
- Keep the track free of dust and debris.
- Check fabric vanes against any care label before using water.

Please avoid

- Do not pull the vanes along the track by hand.
- Do not use bleach, solvents or abrasive cleaners.
- Do not leave the cords or chains loose where children can reach them.

If something is not right

A vane has come off

Do not force it back. Many can be re-hung, but if the carrier is broken we can replace it.

The vanes will not turn together

The track or the control may need adjusting, so please call us.

These are general guides. Always follow any care label or instructions supplied with your product, and if you are unsure about a stain, a fabric or a repair, ask us before you try anything.

Need a hand? Call 01332 280585 | sales@rayneswayblinds.com

rayneswayblinds.com/care-guides/